

EEKit Installation Manual

www.elecycles.com

Thick Washer*2

Spring Washer*2

Thin Washer*6

1.Accessory List

Anti-slip Nut*2

5.Installation Steps(continued) Adjust the disk brake 05 Reason of disk collision Disk deformation correction adjustment: 1.Disk deformation 2. Calliper tilt Use a monkey wrench to clamp the disk and correct the deformation. 10 5.Installation Steps(continued) Adjust the disk brake 05 Adjust the calliper:

Loosen this bolt Loosen these 2 to adjust the bolts to adjust space of the the position of brake linings. the calliper. 11 Setting The Parameters 1 Scan the QR code or search "wepower" Set the parameters according to the "Wepower APP Instruction" in APP store or Google play to download the APP. wepower

Google play App Store You can ride easily after setting the parameters. 12 For your safety, please read the safety instruction below carefully.

7. Safty Instruction Please obey the local e-bike rules. riding. first time you use or when it is not right. Check the bike especially the brake before riding. • Do not accelerate or decelerate sharply. Do not ride over speed, The maximum safety in European is 25km/h. Charge the battery when it is low. Try to protect human from hurt first when there is a risk. · Do not put the wepower wheel under the strong sunshine when the temperature is very high and do not put it in the rain. Understand and obey local traffic rules before riding. Watch out for the object and people on the road in order to avoid hit.

· Please make sure to put on the cycling helmet, grooves, elbow pad, knee pads before Set the weight of the bike and rider as actual in the App, do not set the weights higher than actual weights. Correct the Gyro angle by the way indicated in the App before the 13 8. Maintenance If there is dirt on the wheel, wipe with wet cloth. If the dirt is hard to clean, use a little detergent and wipe it with wet cloth. Notice: Do not use alcohol, gas, kerosene and other similar chemical solvents which are corrosive and volatile to clean the hub. Do not use high pressure water gun to flush the wheel. for a long time.

Do not place the bike in wet environment or under strong sunshine when you Don't use it 14 Contact us Website: www.elecycles.com E-mail: support@elecycles.com